

PL - KOLEJNOŚĆ PODŁĄCZANIA PRZEWODÓW: MASA, +24 V, USTAWIĆ NUMER PROGRAMU DLA DANEGO AUTA, PODŁĄCZYĆ CANL I CANH.

EN - WIRE CONNECTING ORDER: GROUND, +24V, SET THE PROGRAM NUMBER FOR THE GIVEN VEHICLE, CONNECT CAN-L AND CAN-H.

RU - ПОСЛЕДОВАТЕЛЬНОСТЬ ПОДКЛЮЧЕНИЯ ПРОВОДОВ: МАССА, +24 В, УСТАНОВИТЬ НОМЕР ПРОГРАММЫ ДЛЯ ОПРЕДЕЛЕННОГО АВТОМОБИЛЯ, ПОДКЛЮЧИТЬ CAN-L И CAN-H.

